

## Can I make inches and feet the default when using my dimension tools? Yes.

SplashWorks uses decimals as the default, to change defaults we use the Options Box or Q is the short cut key.

Go to Options / Options / Dimension Tab


Under Dimension Type use the Drop down to go to Linear Dimension, Dimension Arc, Dimension Radius, and Dimension Extended.

Under Dimension Text / Format use the drop down to go to 1' 6 3/4"

While we are here lets set Location at the first choice from the drop down.

Precision: at .001 and Orientation: at Horizontal. Don't forget to select Same Size as Normal text. You must select SAVE and APPLY with each Dimension Type change.

SplashWorks has the ability to allow changes directly from the Dimension tools.



Another nice feature of SplashWorks is the Coordinate Bar, which we can change to view inches and feet.

Go to Options / Options / General Tab / select Numeric Format (toward the bottom of the screen) Under Coordinate Format use the drop down to choose 1' 6 3/4 " Click OK / Click Save As Default / Apply / OK. Now you can view inches and feet while you're drawing. You can turn on and off Tool Bars by Right Clicking any tool bar and choose the ones you want to view. Keep in mind the more tool bars you have up, the less screen you will have to view.

